#### U.S. DEPARTMENT OF HOMELAND SECURITY Federal Emergency Management Agency National Flood Insurance Program

OMB No. 1660-0008 Expiration Date: November 30, 2022

# **ELEVATION CERTIFICATE**

Important: Follow the instructions on pages 1-9.

Copy all pages of this Elevation Certificate and all attachments for (1) community official, (2) insurance agent/company, and (3) building owner.

SECTION A - PROPERTY INFORMATION						FOR INSU	RANCE COMPANY USE
A1. Building Owner's Name  Ernest Signature Custom Homes, LLC						Policy Num	ber:
			·	Dida Na Va	2.0 Dente and		
A2. Building Street Address (including Apt., Unit, Suite, and/or Bldg. No.) or P.O. Route and Box No.  24 Spoonbill Drive							IAIC Number:
City		"		State		ZIP Code	
Richmond Hill				Georgia		31324	
A3. Property Descr Lot 186A Dunham M		nd Block Numbers, Ta C (2015)	₃x Parce	l Number, Le	gal Description, et	c.)	
A4. Building Use (e	e.g., Resider	ntial, Non-Residential,	Addition	, Accessory,	etc.) Residentia	al	
A5. Latitude/Longit	ude: Lat. 3	31°51'11.57"N	Long8	31°16'49.54"V	V Horizonta	I Datum: NAD 1	1927 X NAD 1983
A6. Attach at least	2 photograp	hs of the building if the	e Certific	ate is being ι	used to obtain floo	d insurance.	
A7. Building Diagra	m Number	1B					
A8. For a building v	vith a crawls	space or enclosure(s):					
a) Square foot	age of crawl	space or enclosure(s)	-		N/A sq ft		
b) Number of p	ermanent flo	ood openings in the cr	awlspace	e or enclosur	∍(s) within 1.0 foot	above adjacent gra	ade N/A
c) Total net are	a of flood o	penings in A8.b		N/A sqin	1		0
d) Engineered	flood openir	ngs? 🗌 Yes 🗵 N	10				
A9. For a building w	ith an attach	ned garage:					
a) Square foots	age of attach	ned garage		445.00 sq ft			
b) Number of p	ermanent flo	ood openings in the at	tached g	arage within	1.0 foot above adj	acent grade 4	
		penings in A9.b		544.00 sq		-	
d) Engineered flood openings?   Yes   No							
4	SE	CTION B - FLOOD I	NSURA	NCE RATE	MAP (FIRM) INF	ORMATION	
B1. NFIP Communit	•	ommunity Number		B2. County			B3. State
Bryan County 13001	16			Bryan (unin	corporated)		Georgia
B4. Map/Panel Number	B5. Suffix	B6. FIRM Index Date	Effe	RM Panel ective/ vised Date	B8. Flood Zone(s)	B9. Base Flood E (Zone AO, use	levation(s) Base Flood Depth)
13029C0375	D	08-02-2018	08-02-2		AE	9.0	
B10. Indicate the so	ource of the	Base Flood Elevation	(BFE) da	ata or base fle	ood depth entered	in Item B9:	
☐ FIS Profile ☒ FIRM ☐ Community Determined ☐ Other/Source:							
B11. Indicate elevat	tion datum u	ised for BFE in Item B	9: 🔲 N	GVD 1929	⊠ NAVD 1988	Other/Source:	
B12. Is the building	located in a	Coastal Barrier Reso	urces Sy	stem (CBRS	) area or Otherwis	e Protected Area (C	PA)? ☐ Yes ☒ No
Designation D				☐ OPA		•	,
	-			_			

# **ELEVATION CERTIFICATE**

OMB No. 1660-0008 Expiration Date: November 30, 2022

IMPORTANT: In these spaces, copy the correspondi	ng Information from Se	ection A.	FOR	NSURANC	CE COMPANY USE
Building Street Address (including Apt., Unit, Suite, and 24 Spoonbill Drive	/or Bldg. No.) or P.O. Ro	ute and Box No.		Number:	
City State ZIP Code		Company NAIC Number			
Richmond Hill Georgia 31324					
SECTION C - BUILDING E	LEVATION INFORMA	TION (SURVEY R	EQUIRI	ED)	
<ul> <li>C1. Building elevations are based on: Construct</li> <li>*A new Elevation Certificate will be required when</li> <li>C2. Elevations – Zones A1–A30, AE, AH, A (with BFE)</li> </ul>	construction of the build			_	hed Construction
Complete Items C2.a–h below according to the bu Benchmark Utilized: AB3037	uilding diagram specified  Vertical Datum	in Item A7. In Puert	o Rico	only, enter	meters.
Indicate elevation datum used for the elevations in	items a) through h) bek	ow.			
☐ NGVD 1929  ☐ NAVD 1988  ☐ Othe	r/Source:				
Datum used for building elevations must be the sa	me as that used for the	BFE.	01		
a) Top of bottom floor (including basement, crawl	energ or analogues floor	<b>"</b> \	10.9	eck the me	easurement used.
	space, or enclosure 1100	()		_	☐ meters
b) Top of the next higher floor		-	21.4	⊠ feet	∐ meters
c) Bottom of the lowest horizontal structural mem	ber (V Zones only)		N/A	⊠ feet	meters
d) Attached garage (top of slab)		-	9.6	⊠ feet	meters
<ul> <li>e) Lowest elevation of machinery or equipment so (Describe type of equipment and location in Co</li> </ul>	ervicing the building emments)		10.9	⊠ feet	meters
<ul> <li>f) Lowest adjacent (finished) grade next to building</li> </ul>	ng (LAG)		7.6	✓ feet	meters meters
g) Highest adjacent (finished) grade next to buildi	ng (HAG)	-	9.5	✓ feet	meters meters
<ul> <li>h) Lowest adjacent grade at lowest elevation of destructural support</li> </ul>	eck or stairs, including		7.6	⊠ feet	meters
SECTION D - SURVEYO	R, ENGINEER, OR AR	CHITECT CERTIFI	CATIO	N	
This certification is to be signed and sealed by a land so I certify that the information on this Certificate represent statement may be punishable by fine or imprisonment.	its my best efforts to inte	roret the data availa	law to o	certify elev	ration information. That any false
Were latitude and longitude in Section A provided by a		CASAMMAN SC SEMIS		Check here	e if attachments.
Certifier's Name	License Number		T		
David A. Brunson	2538			0	RG
Title President			1	G REGIS	TERED V
Company Name			7 (	No	2538 *
Southeast Georgia Surveying, P.C.			_  \	1 3	
Address 10 Miller Drive			\	ALINO	
City Richmond Hill	State Georgia	ZIP Code 31324	7	A	BIL
Signature	Date 10-21-2022	Telephone (912) 756-2211	Ext.		
Copy all pages of this Elevation Certificate and all attachn	nents for (1) community o	fficial, (2) insurance a	agent/co	mpany, and	d (3) building owner.
Comments (including type of equipment and location, p Job #22-24 Lot 186A Dunham Marsh Ph 3C (2015) equipment for C2e is an A/C unit located on the right sic Flood Flaps, LLC model # FFNF05 with a total net area louver vents with a total net area of 104 square inches.	Latitude and Longitude de of house. The two ve of 440 square inches.	nts located at the fro The two vents in the	ont of ho	use are er	naineered vents by

# **ELEVATION CERTIFICATE**

OMB No. 1660-0008 Expiration Date: November 30, 2022

	TANT: In these spaces, copy the correspond			FOR INSURANCE COMPANY USE
24 Spc	g Street Address (including Apt., Unit, Suite, and conbill Drive	i/or Bldg. No.) or P.O.	Route and Box No.	Policy Number:
City Richmo	ond Hill	Georgia	ZIP Code 31324	Company NAIC Number
	SECTION E - BUILDING EL FOR ZONI	EVATION INFORMA E AO AND ZONE A (	TION (SURVEY NOT WITHOUT BFE)	REQUIRED)
For Zor comple enter n	nes AO and A (without BFE), complete Items E1 ste Sections A, B,and C. For Items E1–E4, use n neters.	–E5. If the Certificate atural grade, if availat	is intended to support a ble. Check the measure	LOMA or LOMR-F request, ment used. In Puerto Rico only,
the	ovide elevation information for the following and e highest adjacent grade (HAG) and the lowest a Top of bottom floor (including basement,	check the appropriate idjacent grade (LAG).	boxes to show whethe	r the elevation is above or below
	crawlspace, or enclosure) is  Top of bottom floor (including basement, crawlspace, or enclosure) is			
the	r Building Diagrams 6–9 with permanent flood of e next higher floor (elevation C2.b in	penings provided in Sa	ection A Items 8 and/or	9 (see pages 1–2 of Instructions),
	e diagrams) of the building is ached garage (top of slab) is			
se	p of platform of machinery and/or equipment rvicing the building is	-		
E5. Zo flo	ne AO only: If no flood depth number is available odplain management ordinance?   Yes	e, is the top of the bott No Unknown.	om floor elevated in ac The local official must o	cordance with the community's certify this information in Section G.
	SECTION F - PROPERTY OWN	IER (OR OWNER'S R	EPRESENTATIVE) CE	RTIFICATION
The pro	perty owner or owner's authorized representativ nity-issued BFE) or Zone AO must sign here. Th	e who completes Sections statements in Section	tions A, B, and E for Zo ons A, B, and E are cor	ne A (without a FEMA-issued or rect to the best of my knowledge.
Propert	y Owner or Owner's Authorized Representative's	Name		
Address	3	City	Sta	ate ZIP Code
Signatu	re w	Date	Te	lephone
Comme	nts			
				ĺ
				Check here if attachments.

# **ELEVATION CERTIFICATE**

OMB No. 1660-0008 Expiration Date: November 30, 2022

IMPORTANT: In these spaces, copy the cor				FOR INSURANCE COMPANY USE
Building Street Address (including Apt., Unit, 9 24 Spoonbill Drive	Suite, and/or Bldg.	No.) or P.O. Route and Box	No.	Policy Number:
City Richmond Hill	State Georgia	ZIP Code 31324		Company NAIC Number
SECT	ION G - COMMUN	ITY INFORMATION (OPTIC	ONAL)	
The local official who is authorized by law or of Sections A, B, C (or E), and G of this Elevation used in Items G8–G10. In Puerto Rico only, e	n Certificate. Comp inter meters.	plete the applicable item(s) a	and sign	below. Check the measurement
G1. The information in Section C was ta engineer, or architect who is authoridata in the Comments area below.)	ken from other doc ized by law to certif	umentation that has been si y elevation information. (Ind	igned ar licate the	nd sealed by a licensed surveyor, e source and date of the elevation
G2. A community official completed Sec or Zone AO.	tion E for a building	g located in Zone A (without	a FEMA	A-issued or community-issued BFE)
G3. The following information (Items G4	-G10) is provided	for community floodplain ma	anageme	ent purposes.
G4. Permit Number	G5. Date Permi	t Issued		Pate Certificate of ompliance/Occupancy Issued
G7. This permit has been issued for:	New Construction	on 🔲 Substantial Improvem	nent	
G8. Elevation of as-built lowest floor (includir of the building:	ng basement)		feet	meters Datum
G9. BFE or (in Zone AO) depth of flooding at	the building site:		☐ feet	meters Datum
G10. Community's design flood elevation:	9		feet	meters Datum
Local Official's Name		Title		
Community Name		Telephone		
Signature		Date		
Comments (including type of equipment and lo	ocation, per C2(e), i	f applicable)		
				_
				Check here if attachments.

## **BUILDING PHOTOGRAPHS**

#### **ELEVATION CERTIFICATE**

See Instructions for Item A6.

OMB No. 1660-0008

Expiration Date: November 30, 2022

IMPORTANT: In these spaces, co	FOR INSURANCE COMPANY USE		
Building Street Address (including	Policy Number:		
24 Spoonbill Drive	ē.		
City	State	ZIP Code	Company NAIC Number
Richmond Hill	Georgia	31324	

If using the Elevation Certificate to obtain NFIP flood insurance, affix at least 2 building photographs below according to the instructions for Item A6. Identify all photographs with date taken; "Front View" and "Rear View"; and, if required, "Right Side View" and "Left Side View." When applicable, photographs must show the foundation with representative examples of the flood openings or vents, as indicated in Section A8. If submitting more photographs than will fit on this page, use the Continuation Page.



Photo One

Photo One Caption Front & Right Side View (showing the lowest servicing equipment for C2e ) taken 10-20-2022

Clear Photo One



Photo Two

Photo Two Caption Rear View taken 10-20-2022

Clear Photo Two

# **BUILDING PHOTOGRAPHS**

# **ELEVATION CERTIFICATE**

Continuation Page

OMB No. 1660-0008

Expiration Date: November 30, 2022

IMPORTANT: In these spaces, co	FOR INSURANCE COMPANY USE Policy Number:		
Building Street Address (including			
24 Spoonbill Drive			
City	State	ZIP Code	Company NAIC Number
Richmond Hill	Georgia	31324	

If submitting more photographs than will fit on the preceding page, affix the additional photographs below. Identify all photographs with: date taken; "Front View" and "Rear View"; and, if required, "Right Side View" and "Left Side View." When applicable, photographs must show the foundation with representative examples of the flood openings or vents, as indicated in Section A8.



Photo Three

Photo Three Caption Left Side View (showing two engineered vents in the garage) taken 10-20-2022

Clear Photo Three



Photo Four

Photo Four Caption Left Side View of garage (showing two louver vents in the garage door) taken 10-20-2022

Clear Photo Four









I-Codes provide recognition in all 50 states Specialty code recognition

www.lcc-es.org | (800) 423-6587 | (562) 699-0543

A Subsidiary of the International Code Council®

# ICC-ES Evaluation Report ESR-3560

**DIVISION: 08 00 00—OPENINGS** 

Section: 08 95 43—Vents/Foundation Flood Vents

REPORT HOLDER:

FLOOD FLAPS®, LLC

**EVALUATION SUBJECT:** 

FLOOD FLAPS® AUTOMATIC FLOOD VENTS: MODELS FFWF12; FFNF12; FFWF08; FFNF08; FFWF05; FFNF05

#### 1.0 EVALUATION SCOPE

Compliance with the following codes:

- 2018, 2015, 2012 and 2009 International Building Code® (IBC)
- 2018, 2015, 2012 and 2009 International Residential Code® (IRC)

### Properties evaluated:

- Physical operation
- Water flow
- Weathering

#### **2.0 USES**

Flood Flaps® automatic flood vents are used to provide for the equalization of hydrostatic flood forces on exterior walls. Certain models also allow natural ventilation.

#### 3.0 DESCRIPTION

#### 3.1 General:

Flood Flaps® automatic flood vents are engineered mechanically operated flood vents (FVs) that automatically allow flood waters to enter and exit enclosed areas. The FVs are constructed of ABS plastic which serves as the FV's housing, and a front grill that contains an anodized metal screen imbedded in polypropylene plastic. On contact with rising flood water, the grill will disengage from its secured position, allowing flood water and debris to flow through in either direction. The FVs are available in two series as described in Section 3.3.

The sealed series models contain two rubber flaps that close the FV to the passage of air when using with conditioned areas or sealed crawl spaces. In the same manner as the grill, the two rubber flaps are pushed open

Reissued September 2021

This report is subject to renewal September 2022.

by water pressure, allowing water and debris to flow through the FV in either direction. See Figure 1 for an illustration of the Flood Flaps® automatic FV.

#### 3.2 Engineered Opening:

The Flood Flaps® automatic FVs comply with the design principle noted in Sections 2.7.2.2 and 2.7.3 of ASCE/SEI 24-14 (2018 and 2015 IBC and IRC) [Section 2.6.2.2 of ASCE/SEI 24-05 (2012 and 2009 IBC and IRC)] for a rate of rise and fall of 5 feet per hour (0.423 mm/s). In order to comply with the engineered opening requirement of ASCE/SEI 24, Flood Flaps® automatic FVs must be installed in accordance with Section 4.0.

# 3.3 Flood Vent Series Models:

Flood Flaps® automatic FVs are available in two series with multiple models and sizes as described in Table 1. The sealed series models, designated FFWF, include two rubber flaps for the prevention of air flow. The multi-purpose series, designated FFNF, omits the rubber flaps.

## 3.4 Natural Ventilation:

Flood Flaps® automatic FV models FFNF12, FFNF08, FFNF05, and FFNF02 have metal screens with ¼ inch by ¼ inch (6 mm by 6 mm) openings and provide 37 square inches (0.02 m²) of net free opening to supply natural ventilation for under-floor ventilation. Flood Flaps® automatic FV models FFWF12, FFWF08, and FFWF05 have not been evaluated for use as openings for under-floor ventilation.

# 4.0 DESIGN AND INSTALLATION

Flood Flaps® automatic FVs are designed to be installed into walls of existing or new construction. Installation of the FVs must be in accordance with the manufacturer's instructions, the applicable code and this report. Flood Flaps® automatic FVs can be installed in wood, masonry and concrete walls up to a thickness of 12 inches (305 mm). In order to comply with the engineered opening design principle noted in Sections 2.7.2.2 and 2.7.3 of ASCE/SEI 24-14 (2018 and 2015 IBC and IRC) [Section 2.6.2.2 of ASCE/SEI 24-05 (2012 and 2009 IBC and IRC)], the Flood Flaps® FVs must be installed as follows:

- With a minimum of two openings on different sides of each enclosed area.
- With a minimum of one FV for every 220 square feet (20 m²) of enclosed area.
- Below the base flood elevation.



With the bottom of the FV located a maximum of 12 inches (305 mm) above grade.

#### 5.0 CONDITIONS OF USE

The Flood Flaps® automatic flood vents described in this report comply with, or are suitable alternatives to what is specified in, those codes listed in Section 1.0 of this report, subject to the following conditions:

- **5.1** The Flood Flaps® automatic FVs must be installed in accordance with this report, the applicable code and the manufacturer's installation instructions. In the event of a conflict, the instructions in this report govern.
- 5.2 The Flood Flaps® automatic FVs must not be used in place of "breakaway walls" In coastal high hazard areas, but are permitted for use in conjunction with breakaway walls in other areas.

#### 6.0 EVIDENCE SUBMITTED

Data in accordance with the ICC-ES Acceptance Criteria for Mechanically Operated Flood Vents (AC364), dated August 2015 (editorially revised October 2017).

#### 7.0 IDENTIFICATION

- 7.1 The Flood Flaps® models recognized in this report are identified by a label bearing the manufacturer's name, the model number, and the evaluation report number (ESR-3560).
- 7.2 The report holder's contact information is the following:

FLOOD FLAPS®, LLC POST OFFICE BOX 1003 ISLE OF PALMS, SOUTH CAROLINA 29451 (843) 881-0190

www.floodflaps.com info@floodflaps.com


# TABLE 1—FLOOD FLAP AUTOMATIC FLOOD VENT MODEL SIZES

MODEL NUMBER	MODEL DESIGNATION	ROUGH OPENING (Width X Height) (inches)	VENT SIZE (W X H X D) (inches)	ENCLOSED AREA COVERAGE (ft²)	NET FREE AREA OPENING <sup>1</sup> (in <sup>2</sup> )
FFWF12	Sealed Series	16 x 8	15 <sup>5</sup> / <sub>8</sub> X 7 <sup>3</sup> / <sub>4</sub> X 12	220	NA NA
FFNF12	Multi-Purpose	16 x 8	15 <sup>5</sup> / <sub>8</sub> X 7 <sup>3</sup> / <sub>4</sub> X 12	220	37
FFWF08	Sealed Series	16 x 8	155/8 × 73/4 × 8	220	NA
FFNF08	Multi-Purpose	16 x 8	15 <sup>6</sup> / <sub>8</sub> × 7 <sup>3</sup> / <sub>4</sub> × 8	220	37
FFWF05	Sealed Series	16 x 8	15 <sup>5</sup> / <sub>8</sub> x 7 <sup>3</sup> / <sub>4</sub> x 5	220	NA NA
FFNF05	Multi-Purpose	16 x 8	15 <sup>5</sup> / <sub>8</sub> x 7 <sup>3</sup> / <sub>4</sub> x 5	220	37

For SI: 1 inch = 25.4 mm;  $1 f^2 = 0.093 m^2$ 

<sup>&</sup>lt;sup>1</sup>For under-floor ventilation only





white aluminum and can be installed in the bottom section of the door. design pressures on the wind load approval drawings. Louvers are pre-painted Wayne-Dalton Louvers have been tested per ANSI/DASMA 108 and meet the

square inches of net area open for flood waters. For Models 5120, 9100, 9605, 8300, 8500, 5150, and 5200, each louver has 36

open for flood waters. For Models 8000, 8100, and 8200, each louver has 52 square inches of net area